





\* Read and understand the Owner's Manual before operating the generator.




## ▶ How to start



1 Check the Engine oil




2 Fuel cock ON



3 Choke ON/OFF




4 Switch ON



5 Start



6 (Choke off)





7 Plug-in



## ▶ How to stop 7 → 4 → 2

## Safety! be careful!






## Maintenance Schedule

👁️: Check   🔄: Change   🧼: Clean   🔧: Check-Readjust

| Regular Service Period | Before each use | First month or 20 Hours                      | Every 3 months or 50 Hours | Every 6 months or 100 Hours | Every year or 300 Hours                 |
|------------------------|-----------------|--|----------------------------|-----------------------------|---|
| Engine oil             | 👁️              |  |                            |                             |   |
| Air cleaner            |                 | 🔄  |                            | 🔄                           |   |
| Spark plug             |                 |  | 🧼                          | 🔧                           | 🔄                                       |
| Valve clearance        |                 | Take the engine to a Honda servicing dealer. |                            |                             | 🔧                                       |
| Combustion chamber     |                 | 🧼 After every 500 Hours                      |                            |                             |   |
| Fuel tank & filter     |                 |  |                            | 🧼                           |   |
| Fuel line              |                 | 👁️   |                            |                             | 👁️ Every 2 years (Replace if necessary) |

\*Clean the air cleaner when used in dusty areas every 10 hours or once a day




\* Read and understand the Owner's Manual before operating the generator.

## ▶ Spark Plug



## ▶ Engine Oil



## ▶ Prolonged storage



## ▶ Air Cleaner Element

